




Part No.	Description	Qty.
3	Air cap seal	1
6	Fluid nozzle	1
8	Phillips Screw	2
10	Air adjusting valve	1
11	Air adjusting seat	1
16	Snap retaining ring (E-ring)	1
17	Pattern control needle	1
18	Retaining ring	2
19	Pattern control spring	1
20	O-ring 2.5 × 2.1	1
24	O-ring 4.5 × 1.8	2
25	O-ring 5.2 × 1.9	1
28	Fluid needle	1
30	Fluid needle adjusting seat	1
35	Packing nut	1
36	Sealing washer	1
40	Canister gasket	1
42	Material tube	1
F	Pattern Control Knob	1
G	Fluid control knob	1
H	Side knob	2
I	Air inlet	1
L	Canister	1
M	Air cap (internal mix)	1