





PART	DESCRIPTION	QTY
1	Screw	1
2	Washer	1
3	Nut	1
31	Roll Pin	1
33	Trigger	1

Parts List

Part	Description	Qty
1	Screw	1
2	Washer	1
3	Nut	1
4	Cutting Disc Washer	1
5	Cutting Disc	1
6	Shaft	1
7	Spindle Lock Nut	1
8	Locking Nut	1
9	Cutting Disc Cover	1
10	Connector Nut	1
11	Spindle Lock Housing	1
12	Spindle Lock Spring	1
13	Spring Washer	1
14	Bearing	1
15	Pin	1
16	Rotor Washer	1
17	A-Cap	1
18	Rotor	1
19	Blades	4
20	Cylinder	1
21	Alignment Pin	1
22	B-Cap	1
23	Bearing	1
24	Housing	1
25	O-ring	1
26	Direction Switch	1
27	Pin	1
28	Spring	1
29	Switch Pin	1
30	Safety Lever	1
31	Roll Pin	1
32	Spring	1
33	Trigger	1
34	Switch Valve	1
35	O-ring	1
36	O-ring	2
37	Roll Pin	1
38	Muffler	1
39	Housing Cover	1
40	O-ring	1
41	Air Inlet Connector	1
42	Metal Filter	1



Parts List

Part	Description	Qty			
1	Screw	1	29	Switch Pin	1
2	Washer	1	30	Safety Lever	1
3	Nut	1	31	Roll Pin	1
4	Cutting Disc Washer	1	32	Spring	1
5	Cutting Disc	1	33	Trigger	1
6	Shaft	1	34	Switch Valve	1
7	Spindle Lock Nut	1	35	O-ring	1
8	Locking Nut	1	36	O-ring	2
9	Cutting Disc Cover	1	37	Roll Pin	1
10	Connector Nut	1	38	Muffler	1
11	Spindle Lock Housing	1	39	Housing Cover	1
12	Spindle Lock Spring	1	40	O-ring	1
13	Spring Washer	1	41	Air Inlet Connector	1
14	Bearing	1	42	Metal Filter	1
15	Pin	1			
16	Rotor Washer	1			
17	A-Cap	1			
18	Rotor	1			
19	Blades	4			
20	Cylinder	1			
21	Alignment Pin	1			
22	B-Cap	1			
23	Bearing	1			
24	Housing	1			
25	O-ring	1			
26	Direction Switch	1			
27	Pin	1			
28	Spring	1			

PART	DESCRIPTION	QTY
1	Screw	1
2	Washer	1
3	Nut	1
31	Roll Pin	1
33	Trigger	1