




Part No.	Description	Qty.
1	Outer plate	1
2	Screw	6
3	Coil spring	1
4	Left reel drum	1
5	Screw	4
6	Retaining ring	1
7	Right reel drum	1
8	Drum connector	1
9	Connect insert (1)	4
10	Connect insert (2)	1
11	Spring	2
12	E-clip	1
13	Spring bolt	1
14	Clip	1
15	Set bolt	1
16	Axle	1
17	O-ring	2
18	Cover plate	1
19	Screw	4
20	Connector	1
21	Fix dog (1)	1
22	Fix dog (2)	1
23	Screw	2
24	Inner plate	1
25	Screw	1
L	Reel bracket	1
27	Hose guide plate	1
J	Roller bracket	1
M	Fix plate	1
K	Set screw	3
31	Protective cap	1
D	Bottom base	1
E	Bolt	3
34	Spacer	6
35	Hex nut	3
36	Screw	6
37	Spacer	6
38	Hex nut	6
39	Roller plate	1
40	Short roller	2
41	Short pin	2
42	Long roller	2
43	Long pin	2
44	Top bumper	1
45	Side bumper (1)	1
46	Side bumper (2)	1
47	Screw	2
48	Nut	2
49	Lead-in Hose	1

REPLACEMENT PART	DESCRIPTION	QTY	REPLACEMENT PART	DESCRIPTION	QTY
3	Coil Spring	1	24	Inner Plate	1
6	Retaining Ring	1	L	Reel Bracket	1
8	Lever	1	D	Bottom Base	1
11,12,15,16,17	Axle Assembly	1	36-43	Hose Guide Assembly	1
17	O-Ring	2	44,45,46,47	Bumper Assembly	1
18	Cover Plate	1	49	Lead-in Hose	1
20	Connector	1	M	Fix Plate	1
21,22	Fix Dog Assembly	1			