

45pc Spray Gun Kit - Gravity Feed Spay Gun PARTS DIAGRAM - *NEW MODEL*

This diagram illustrates the exploded view of a spray gun assembly, showing the main body and various internal and external components. The components are numbered as follows:

- 1**: Trigger gun body
- 2**: Trigger gun body cap
- 3**: Trigger gun body cap seal
- 4**: Trigger gun body cap seal
- 5**: Trigger gun body cap seal
- 6**: Trigger gun body cap seal
- 7**: Trigger gun body cap seal
- 8**: Trigger gun body cap seal
- 9**: Trigger gun body cap seal
- 10**: Trigger gun body cap seal
- 11**: Trigger gun body cap seal
- 12**: Trigger gun body cap seal
- 13**: Trigger gun body cap seal
- 14**: Trigger gun body cap seal
- 15**: Trigger gun body cap seal
- 16**: Trigger gun body cap seal
- 17**: Trigger gun body cap seal
- 18**: Trigger gun body cap seal
- 19**: Trigger gun body cap seal
- 20**: Trigger gun body cap seal
- 21**: Trigger gun body cap seal
- 22**: Trigger gun body cap seal
- 23**: Trigger gun body cap seal
- 24**: Trigger gun body cap seal
- 25**: Trigger gun body cap seal
- 26**: Trigger gun body cap seal
- 27**: Trigger gun body cap seal
- 28**: Trigger gun body cap seal
- 29**: Trigger gun body cap seal
- 30**: Trigger gun body cap seal
- 31**: Trigger gun body cap seal
- 32**: Trigger gun body cap seal
- 33**: Trigger gun body cap seal

Part No.	Description	Qty.
1	Flow Cap Lock Nut	1
2	Flow Cap Washer	1
3	Flow Cap	1
4	Flow Cap Ring	1
5	Nozzle	1
6	Gun Body	1
7	Cup Connector	1
8	Paint Cup	1
9	Needle	1
10	Washer	1
11	Spring	1
12	Pattern Control O-Ring	1
13	Pattern Control Nut	1
14	Pattern Control Knob	1
15	Needle Sleeve Pad	1
16	Needle Adjustment Holder	1
17	Fluid Adjustment Needle	1
18	Needle Holder	1
19	Needle Spring	1
20	Fluid Control Knob	1
21	Air Inlet	1
22	Pattern Control Needle	1
23	Needle Guide Screw	1
24	Plastic Needle	1
25	Valve Spring	1
26	Valve Needle	1
27	Valve Gasket	1
28	Valve Sleeve	1
29	Trigger Pin	1
30	Trigger	1
31	Trigger Pin Holder	1
32	E-Clip	1
33	Trigger Pad	1