




REPLACEMENT PART	DESCRIPTION	QTY
1	Hex Screws	4
2	Split Washers	4
4	Gasket	1
5	Circle Clip	1
6	O-Ring	1
7	Anvil	1
8	Hammer Pins	2
9	Hammer Cage	1
10	Hammer	1
11	Bearing	1
16	Vanes	6
17	Rotor	1
21	Gasket	1
23	Reversing Switch	1
20-37, 39-54	Body Assembly	1

PART	Description	QTY
1	Hex Screw	8
2	Split Washers	8
3	Hammer Case	1
4	Gasket	1
5	Circlip	1
6	O-Ring	1
7	Anvil	1
8	Hammer Pin	2
9	Hammer Cage	1
10	Hammer	1
11	Bearing	1
12	Front End Plate	1
13	Plug	8
14	Cylinder	1
15	Pin	1
16	Vane	6
17	Rotor	1
18	Rear End Plate	1
19	Bearing	4
20	Handle	1
21	Gasket	1
22	Back Cover	1
23	Reversing Switch	1
24	Valve Bushing	1
25	Gasket	4
26	Hex Screw	4
27	Inlet Gasket	1
28	Rubber Gasket	1
29	Inlet Valve	1
30	Inlet Spring	1
31	O-Ring	2
32	Intake Knob	1
33	Spring	1
34	Plug	1
35	Retaining Ring	1
36	Paper Pad	1
37	O-Ring	1
38	Stall Knob	1
39	O-Ring	1
40	Hand Handle	1
41	Pin	1
42	O-Ring	1
43	Copper Sleeve	1
44	Trigger Pin	1
45	Trigger	1
46	O-Ring	1
47	Rear Air Cover	1
48	O-Ring	1
49	O-Ring	1
50	Air Inlet	1
51	Air Inlet Screen	1
52	Circlip	1
53	Gasket	1
54	Body	1